

Pictorial index


Exterior







Pictorial index


Interior






Interior





Pictorial index

Instrument panel



Without navigation system Clock P.377 18:88 * * Air conditionina Security indicator system P. 256 P. 98, 100 Rear window and outside rear view mirror defogger Emergency flasher switch P. 264 switch P. 488 With navigation system Navigation system*1 Emergency flasher switch P. 488 Clock*1 Security indicator

*: If equipped

Air conditioning

system*1

*1. Refer to "Navigation System Owner's Manual".
*2: For vehicles with a navigation system, refer to the "Navigation System Owner's Manual".

P. 98, 100

Rear window and outside rear view mirror defogger switch*1

Instrument panel

В Talk switch * P. 337 *2 Telephone switches * P. 337 *2 Audio remote Multi-information control switches P.312 *2 switches P.172 Distance switch * P. 208 Horn P.163 LKA (Lane Keeping Assist) switch* P. 221 Cruise control switch* P. 204 Dynamic radar cruise control switch* P. 208

